

# RÊVE

## Installation Instructions

### QUALITY CHECK

Please check whether the delivered wallpaper fully meets your expectations. Before starting installation, we recommend carefully inspecting each roll to ensure there are no visible damages, the patterns align correctly, and the color and shade of the wallpaper match your preferences.

### 1 .....● INSPECTION

### BEFORE INSTALLATION .....● 2

#### BEFORE INSTALLATION

We recommend taking the wallpaper out of the packaging and laying it flat on a smooth surface at least 24 hours before installation. Ensure the wallpaper remains undisturbed during this time and avoid exposure to drafts in the room.

#### TOOLS & MATERIALS REQUIRED

Primer (deep-penetrating, with antifungal properties), adhesive for non-woven or vinyl wallpaper, natural sponge, clean, dry cloth, glue brush, wide rubber roller for pressing wallpaper, glue roller, wallpaper brush, pencil, narrow rubber roller for pressing wallpaper, measuring tape, snap-off utility knife, level, plastic spatula/trowel, wallpaper knife

### 3 .....● TOOLS REQUIRED

### PREPARING THE WALL SURFACE .....● 4

#### PREPARING THE WALL SURFACE

The wall where the wallpaper will be applied must be clean, dry, smooth, and slightly absorbent. For light-colored wallpapers, ensure the wall has a uniform color. Heavy dirt, stains, or markings from pencils or pens may show through the wallpaper.

If applying wallpaper to an unfinished wall (e.g., drywall, gypsum plaster, mineral plaster, concrete), the surface must be primed using a construction primer. If the wall has been painted, it should be washed and degreased before priming. Any old wallpaper layers must be removed. If wall damage is visible after removing old wallpaper, the wall should be evened out and then primed.

#### MEASURING THE WALL

The width of wallpaper panels will be approximately 104 cm, which is the standard width of our wallpapers. To determine the exact placement of each wallpaper strip, it is recommended to mark sections of the appropriate width on the wall. For precise vertical lines, use a level. Avoid drawing lines with dark pencils, as they may show through light-colored wallpaper.

### 5 .....● MEASUREMENT

### ADHESIVE APPLICATION .....● 6

#### APPLYING THE GLUE (INITIAL STEP)

Using a roller, evenly spread the adhesive over the wall's surface where the first wallpaper strip will be applied. Apply a thin layer of glue along the edges using a brush to prevent excess glue from seeping onto the wallpaper's surface. This will mark the placement for the first wallpaper strip. A brush is recommended for applying glue to the edges of the sections.

The wallpaper strips have an overlap, and the installer trims them using a knife directly on the wall during installation.

The cut is made through both layers by slicing the overlap with a single knife stroke. After removing the excess cut-offs, pressing the seam together again should ensure a perfect fit. It is essential to apply glue thoroughly under the seam and carefully attach both parts edge-to-edge, pressing them down with a trowel from bottom to top in a zipper-like motion to make the joint invisible.

Without a sufficient amount of glue, the wallpaper may peel off at the edges. This is not a material defect but a result of incorrect installation.

The cut should be made using a snap-off utility knife, moving from top to bottom, maintaining a vertical line in the center of the overlap. The initial cut can be started with a wallpaper knife resting against a metal spatula. The cut must be made carefully to slice through both wallpaper layers without damaging the underlying surface. Once the cut has been started, insert the snap-off knife into the cut and continue slicing downward to the floor while maintaining a vertical line.

#### FIRST STRIP INSTALLATION

Carefully position the wallpaper strip along the previously marked vertical line where the adhesive has been applied. Ensure the wallpaper is aligned correctly, then smooth it using a wallpaper roller, wallpaper brush, or trowel. If glue gets onto the surface of the wallpaper, gently remove it with a damp sponge or a clean, dry cloth without rubbing.

Wallpaper strips are applied with an overlap. It is recommended to start wallpapering from a window towards the door to make the overlaps less visible.

### 7 .....● INSTALLING THE FIRST WALLPAPER STRIP

### INSTALLING ADDITIONAL STRIPS .....● 8

#### CONTINUING ADHESIVE APPLICATION

Evenly spread the adhesive over the designated area for the next wallpaper strip. This will be the placement for the second strip. Remember to use a brush to apply adhesive along the edges, near the ceiling and floor.

#### INSTALLING THE REMAINING STRIPS

Each wallpaper strip should be applied with an overlap, ensuring that the edges slightly overlap. The seams between the strips should be smoothed out using a rubber roller. If any glue gets on the wallpaper's surface, clean it with a damp sponge and a dry cloth. Trim any excess wallpaper at the ceiling and floor using a sharp wallpaper knife with the help of a spatula.

### 9 .....● INSTALLING THE REMAINING STRIPS

#### TIPS

Before starting the wallpaper application, test a loose piece of wallpaper (scrap) to check its reaction to water cleaning and wiping with a dry cloth.

#### RECOMMENDED COMPLEMENTARY PRODUCTS:

Glue – Dynamic Contract or Dynamic Premiumix Ultra  
Primer – Scala Ultraprimer 08  
Resin – Metropolis Metroresin Gloss / Matte

GOOD LUCK WITH YOUR INSTALLATION!